

EWD-L-MSJ4-X1

User's Guide

(V1.0)

Table of Contents

Product Overview	一、“EWD-L-MSJ4-X1”The main functions and characteristics of the weighing device	
	二、“EWD-L-MSJ4-X1” Weighing Device Working Principle	P3
	三、Controller and display appearance and description	P5
	四、Controller interface diagram and description	P6
	五、Controller dimensions	P8
	六、Installation of sensors and controllers	P9
	七、Button function and instruction code meaning explanation Sensor dimensions and installation location diagram and installation precautions	P10
	八、System debugging methods and instructions (self-learning)	P12
	1.Elevator Rated load rang setting	P13
	2.No-load self-study mode of work	P14
Installation & Adjustment	3.The amount of self-learning work mode	P14
	九、Multiplier parameter setting and description (auxiliary function)	P15
	十、Technical Specifications	P16
System Characteristics		
Promise		P17
Attachments		P18

Note: the system is applicable to "moving car" elevators. Please read the following sections carefully before using.

Notice: in any case, we are only responsible for the quality of the products within the warranty period.

Statement: due to technological progress, the company reserves the right to change the product; For the technical parameters, please refer to the random product manual.

System overview

一. “EWD-L-MSJ4-X1” The main features of the weighing device:

1. The normal work of the product, the direct display of the car internal payload, And can output to the external large screen synchronous display of internal payload, self-learning process is simple.
2. Intelligent programming and control process, according to different customer needs, It is possible to adjust the percentage of load corresponding to any one of the 4-channel switching signals output by the controller and the output of turn-off/turn-off, and the output simulation The amount of the way to modify.
3. Intelligent sensor equipment: the use of high-precision load intelligent sensor, direct detection of car load changes;
4. Wide measurement range (payload can be manually set according to demand), high positioning accuracy, intelligent temperature compensation.
5. Electrical performance in line with the "International Electrotechnical Commission (IEC)" standard requirements;
6. The core uses high precision load cell and high performance single chip microcomputer. Can set all the working parameters.
7. Unique programmable output signal control mode, suitable for a variety of activities of the car to mention the elevator weighing signal on the demand.
8. With the working parameters of artificial fine-tuning correction ability, the elevator can be modified after the artificial correction, so as to achieve the purpose of accurate measurement.
9. Unique sensor + controller+ display design structure, wiring is simple.
10. Everything from the user point of view, easy to install, easy to debug, reduce the use of additional costs, performance and high cost.

二. “EWD-L-MSJ4-X1” working principle:


With the continuous progress of elevator technology, elevator weighing device on its performance has been to the point where it can not be ignored. Elevator on the weighing device of high precision, high reliability, multi-functional needs are imminent. In the sensor technology and micro-computer continues to develop today, the use of high accuracy sensor to detect the elevator car due to load changes caused by

electrical signals.


High accuracy sensor,the use of serial communication technology for its long-distance high-precision non-destructive transmission; sensor comes with 8 ~ 10m signal transmission cable; at the same time,the microcontroller is used to carry out scientific calculation and processing,finally, the payload in the cage can be displayed synchronously on the digital tube of the controller and the large external screen.it can realized the function of weighing the effective load of the elevator car.

三. **Controller and load sensor Appearance :**



1. **Elevator load weighting device“EWD-L-MSJ4-X1”Controller**

Model	EWD-L-MSJ4-X1
Elevator load weighting device“EWD-L-MSJ4-X1”Controller	

2.LED Large Screen Display


Model	Display		
Physical appearance of the monitor			
Qualification definition	Brown	DC24V+	Wire Length 6m
	Blue	COM	
	Black	Signal+	
	Gray	Signal-	

2. The appearance and model name of sensor products:

Appearance			
Denominate	Order type	XCL-T/A	XCL-YH/7910
	Sensor type	“ one type ” load	"Rubber" sensor
Special Version		Include cable length defaults to 8m	

四. **Controller interface diagram and description:**

1. **Controller interface diagram:**



2.Controller port details:

		Function	Explanation	
Switching	1	J1Relay COM port	With the P2 to produce effective logic	Function : Be programmed as“J1 ~ J4”(No load - over load)output signals to
	2	J1Relay Output	system default“J1” : 5Kg No load Dynamic open output	
	3	J2、 J3、 J4 Relay com port	With P4.P5.P6, to produce effective logic	


EWD-L-MSJ4-X1 Series of intelligent elevator weighing device technical documents of the [user manual]

PJ		4	J2 Relay Output	system default“J2”: Light load Dyn. Close output	participate in elevator logic control. 2.Max loading Capacity: DC/AC 48V/500mA
		5	J3 Relay Output	system default“J3” : Related load Dyn close output;	
		6	J4 Relay Output	system default“J4”: Overload Dyn,open output;	
PM	Lock	1	Lock signal COM port	Note the voltage difference and the connection polarity when connecting	
		2	DC+24V lock signal , Can access the door lock signal and brake signal		
PX	Analog	3	0~10V;10~0V;Analog voltage output	Used for pre-torque compensation of the drive system	
		4	COM Connect the governor to the analog common		
PV	Power supply	System power supply port: AC/DC 24V / 200mA			
PG	Sensor connection port	P G1 ~ P G4	PG is connected with sensor with signal cable		
Display	External monitor connection port	Port access black and gray signal line		Power supply: DC+24V/1A	

① It is absolutely impossible to connect the output port other than the "PV" device directly to the external power supply, which may cause permanent damage.

(Note:PX and PM port with Polarity requirements and voltage rating requirements)

五、Controller Dimensions:



六、 Installation method of sensor and controller:

1.A. The "one" type sensor shall be installed in the four corners below the upper beam of the elevator car and the upper part of the rubber pad according to the attached 1.2;

B. "rubber" sensors shall be installed on the floor of the elevator moving car according to appendix 2.2.
4 sensors or 6 sensors shall be installed on the floor of the elevator moving car

2. The controller should be installed in the control box on the top of the car, preferably not close to the electric control system transformer, governor and other equipment of the elevator. In any case, the sensor and controller should be installed away from the heat source;

3. The connection between the sensor and the controller should not be in the same wiring slot with 110V, 220V and other power

sources;

4. Connect the sensor wiring port to the PG port of the controller, and at the same time, PV can access the power line according to the system requirements. Be sure to pay attention to the voltage level;

5. When the system is powered on after the check is correct, the controller should display the corresponding working mode.

七、 Button Function and Instruction Parameter Code Meaning Description :

1.Button Meaning and Function Description:

No.	Button icon	Function	Explanation
1	【■】	Set and confirm Button (SET)	Set a parameter and confirm the internal data function
2	【↶】	Switch / cursor shift Button(SHIFT)	Used to switch the digital display digit
3	【▼】	Data increase Button (ADD)	Change the internal value of the parameter

2.Button to use method description:

(1)Set and confirm button **【■】** Instructions:

When power is displayed, press it **【■】** , Enter the parameter setting status, by **【↶】** and **【▼】** button Enter the setting parameter, Can be set accordingly.Finish setting , press **【■】** button check, Save the parameters.

(2)Switch / cursor shift buttons **【↶】** Instructions:

In the parameter setting state, press once **【↶】** , The cursor moves one by one , to the last one, Press the toggle / cursor shift button **【↶】** And cycle back to the first place.

(3)Data increase button **【▼】** Instructions:

In the parameter setting state, press once **【▼】** , Add one to the cursor bit data, add the maximum value of the set data and then cycle back to the minimum value of the data.

3.With the decimal point of the parameters of the process of adjusting the use of key examples:

After powering on the product, press **【■】** button to enter the instruction setting state. When "00000" is displayed, press **【↶】** button

to move the flashing cursor to the last digital tube. Press **【▼】** key to adjust the digital display to "00001", press **【■】** button to enter the command parameter setting state, digital display "dd - c", press **【■】** buttons to enter this Parameter modification mode, display "00001" means that the decimal point is 1 bit. Press **【↶】** and **【▼】** to change the digital tube display to "00002", press **【■】** key to confirm this parameter is modified, the digital tube decimal point will move one by one. (Note: other instruction item parameters can be modified and confirmed in accordance with this method.)

3.Instruction Parameter Code Meaning Description:

No	Instruction parameter code	Function code	Code default data	Function and explanation
1	00001	dd--c	00001	Display the decimal point position setting, the factory default for the 1-bit display "00001", adjustable 4 decimal point adjustment
2	00002	Lc--01	1000.0	The amount of load range set, according to the different capacity of the elevator directly to the manual set to the load range can be.
3	00003	Bj--1	0005.0	J1 for the no-load signal output corresponding to the car load, the default setting elevator car load 5.0kg: (adjustable range of 0 ~ 15Kg)
		Bj--2	0005.0	J2 for the light load signal output corresponding percentage, the default setting for the amount of 5% output action, adjustable range of 0% to 150%
		BJ--3	0090.0	J3 for the full load signal output corresponding percentage, the default setting for the amount of 90%, the percentage can be adjusted from 0% to 150%
		BJ--4	0105.0	J4 for the overload signal output corresponding percentage, the default setting for the amount of 105%, the percentage can be adjusted from 0% to 150%

EWD-L-MSJ4-X1 Series of intelligent elevator weighing device technical documents of the [user manual]

4	00004	BJ-HL	BJ1-L	J1 relay dynamic output, dynamic (L) / moving (H) adjustable
			BJ2-H	J2 relay moving output, moving off (L) / moving together(H)adjustable
			BJ3-H	J3 relay moving output, dynamic (L) / moving (H) adjustable
			BJ4-L	J4 relay dynamic output, dynamic (L) / moving (H) adjustable
5	00005	Da--c	Da-00	Analog output mode corresponds to P9 ~ P10 terminal port output 0 ~ 10V
			Da-01	Analog output mode corresponds to P9 ~ P10 terminal port output 10 ~ 0V
6	00006	HELP-	---01	Restore factory settings
7	00007	B2--c	B2-01	Multiplier parameter setting, multiplied by the amount of 1 times, "01 ~ 99" value corresponding to the amount of 1 to 99 times the amount of adjustable; ★ multiplier parameters to be modified after the completion of self-learning after the completion of confirmation
8	00008	L-H-2	LL--1	The controller learns the no load parameter;
			HH--1	The controller self - learns the load parameter
9	00009	I-h-2	1000.0	Fine-tuning the coefficient setting to fine-tune the learning results

八、 System debugging methods and instructions (self-learning):

(Here to lift the amount of 1000Kg as an example to describe the load range setting and "no load and the amount of two self-learning" process)

Before the system debugging:


①.Products must be in strict accordance with the "EWD-L-MSJ4-X1 user manual" for self-learning, otherwise it will cause the product

can not be used and product measurement accuracy is not accurate.

②. Before commissioning, it is necessary to specify the weight of the car. The weight of the truck can not exceed the total range of the sensor. Otherwise, the sensor will be damaged and the product will not be used.


1. Elevator load range setting:

Note: ①1. Product digital tube display the default decimal point to 1, the unit is Kg, For example :the case shows "1000.0", that is, 1000kg.





2.Attention:① product no-load self-learning before the car must ensure that there is no load and debris, otherwise it will lead to a greater error in the weighing effect.

② product no-load - the two-point self-learning process, must be "LL-01" first study no-load, "HH - 1" retraining, otherwise it will lead to the product can not be used.



3.Lift the amount of self-learning process:





九、Multiplication parameter setting process description (auxiliary function) :

Note: Repeated parameter debugging must be in the product after the completion of Chapter 8 product self-learning process before they take effect. Multiplier parameter adjustment range of "01 ~ 99", that is, the product multiplier for the amount of 1 to 99 times the amount for customers to choose. The product default multiplier parameter value is 1 times the amount of time to restore the factory settings after the product multiplier parameters are restored to the product default multiplier parameter value of the rated load of 1 times.

1. Multiply parameter setting process:

When the system is displayed normally, Press 【■】 to enter the instruction selection state, and when "00000" is displayed; press 【↶】 and 【▼】 button to change the digital tube display to "00007". Press 【■】 key to display "bz - c", press the 【■】 key again to enter the command parameter to modify the state, the product digital hanging display "bz-01" (after the two digital display "01" That is doubled.

2.for example:

Has completed the amount of 1000kg self-learning process of the product, into the normal working condition. At this time digital tube

Display "1000.0" for the current car payload value of 1000kg.

According to the above parameter setting process will be multiplied parameter value is set to "bz-05", and successfully saved 5 times

Parameter value. At this point the product light load action load value from the original 1000kg * 5% = 50kg also doubled, this

When the product in the 1000kg * 5 * 5% = 250kg output light load switch signal. And so on, the load signal and

The load value of the overload signal is also increased by 5 times. The output of the product will also be based on the load of the elevator Suitable for moving car/fixed car bottom elevator

Corresponding to 5 times the value of the analog output changes.

System Features

十、Technical Specifications:

1	Application	①.Suitable for the use of movable car/fixed car bottom elevator. ②.The load is used in (500 Kg ~5500 Kg) traction drive fixed car bottom elevator.(the measuring range of the sensor depends on the traction ratio of the elevator, the weight of the elevator car and the rated load, special instructions are required when ordering)	
2	Floor Compensation	Artificial changes in learning errors and fine-tuning	
3	Sensitivity	Elevator Rated Capacity/1000kg(Example: The rated capacity is 1000 kg, and the sensitivity is 1 kg) [This data may be affected by elevator mechanical performance)	
4	System Error	≤0.25%(5~40℃)	
5	Non-Linearity	≤0.25%	
6	Output Mode	Programmable 4-way switch signal	①4-channel programmable output modes are: No load, light load,rated load, overload (customer may set the changing range freely) ②Each channel can be programmed as dynamic Close or Open contact ③Contact Capacity: DC/AC 48V/100mA
		Linear analogue	Full compensation range 0~10V;10~0V

EWD-L-MSJ4-X1 Series of intelligent elevator weighing device technical documents of the [user manual]

7	Ambient Temperature	-20~55℃
8	Relative Humidity	20%~90%RH
9	Reaction Time	≤0.25 seconds
10	Power supply	AC/DC24(±10%)V / 200mA
11	Installation Place	Load sensor :under movable car platform Controller :control Cabinet in machine room Display: the users in the cage adjust their positions according to their needs
12	Overall Size	Controller parts: 115×90×40 mm3

Note: Use of strength exceeding the limit parameters listed above may result in abnormal system operation or permanent damage.

Promise

- (1) If this system appears any quality problem of product itself in 1 year after delivery, it will be replaced freely (damage of the product seal will not be dealt with)。
- (2) For any requirement of special functions, make it out by mail.
- (3) Any system abnormality in adjustment or operation, please contact our company directly.

Other

Packing list:	EWD-L-MSJ4-X1 Controller	1set
	Φ4×20mm Fastening Screw sets	4sets
	User's Guide	1pcs
	Display	1pcs
	Sensors and accessories	undetermined


Attached document:

Load sensor dimensions and installation


1. XCL-T/A “—” Load sensor dimensions and installation


1.1 Sensor dimension diagram


1.1.1 The measurement range is 1.5t




1.1.2 The measurement range is 3t, 5t








1.2 Installation:




2. XCL-YH/7910 “rubber” sensor dimensions and installation

2.1 sensor dimensions




2.2 installation




3. XCL-T/B Load sensor dimensions and installation

3.1.1 The measurement range is 1.5T



3.1.2 The measurement range is 3T, 5T



3.2 Installation

